

## Verlegehinweise

### Laying instructions



Starke Verbindung  
Kluge Technik  
Strong contacts  
Clever technology

#### Profil anlegen:

Nachdem der Bodenbelag auf der Setzstufe verlegt wurde, wird das Profil auf die Stufenkante gelegt. Legen Sie hierzu den das Profil so an, dass das Profil mit der Innenecke passgenau auf der Stufenkante anliegt. Die vertikale Nase wird an den Belag der Setzstufe angelegt.

#### Verschrauben:

Mit einem 5 mm Bohrer die zuvor vom Profil auf die Trittstufe übertragenen Bohrungen für die Dübel bohren. Beachten Sie bitte, dass die Treppenstufe ausreichend Festigkeit besitzt. Die Bohrlöcher absaugen, damit keine Bohrspäne in den Löchern oder unter dem Profil verbleiben. Entsprechend den Bohrlöchern verwenden Sie bitte geeignete Dübel und Schrauben. Führen Sie die Dübel in die Bohrlöcher so ein, dass diese komplett in den Bohrlöchern versenkt sind. Bei Holzuntergründen kann die geeignete Schraube direkt durch die Befestigungslöcher in den Untergrund eingeschraubt werden.

#### Verlegen des Bodenbelags:

Damit der Bodenbelag ohne sichtbare Kante verlegt werden kann, empfehlen wir den Profilschenkel per Nivellierung auszugleichen. Verwenden Sie hierzu dem Untergrund entsprechend geeignete Spachtelmassen oder verklebbare Unterlagsmattensysteme. Der Bodenbelag kann anschließend einfach in die Nuten des Treppenantenprofils eingeschoben und verklebt werden.

#### Lay on the profile:

After the flooring has been laid onto the riser, the profile is placed on the step edge. To do this, set the profile so that the profile fits snugly against the step edge with the inside corner. The vertical nose is laying alongside the flooring on the riser.

#### Screw:

Use a 5mm drill to drill the holes for the dowels in the previously transferred places. Please note that the step itself has sufficient strength. Vacuum the holes so that no chips remain in the holes or under the profile. According to the drilled holes please use suitable dowels and screws. Insert the dowels into the holes so that they are completely sunk in the step. For wooden stairs, the appropriate screw can be screwed directly through the mounting holes into the step edge.

#### Laying the flooring:

For laying the flooring without visible edge, we recommend leveling the profile leg by using leveling compound. For this purpose, use suitable leveling compounds or glued underlay systems. The flooring can then simply be inserted into the grooves of the stair nosing profile and glued to the subfloor.

