

Enders[®]


TROLLEY


FOR URBAN II AND eURBAN SERIES




www.enders-germany.com

2072

5		1
1		1
2		1
19		4
20		4
21		4
7		1
8		1



3		1
4		1
19		4
20		4
21		4
9		1
10		1




03a

6		1
14		2
22		4

URBAN II Series ✓

eURBAN Series ✗




03b


6		1
25		1
22		4

URBAN II Series ✗


eURBAN Series ✓



22		M5	8
20			8
24		M5	8




15			2
13			1
23			2
11			1
12			1




06

16		2
18		2



07


17		1
----	---	---




- The gas barbecues of the URBAN II or eURBAN series are not included in the scope of delivery.






- **Attention!** Do not move the grill during operation.





- To fix the grill on the trolley, push the slider head outwards and pull it tight.



URBAN II Series ✓



eURBAN Series ✓



MANUFACTURER

Enders Colsman AG

Brauck 1

58791 Werdohl, Germany

Tel. +49 (0) 2392 97 82 30

We reserve the right to make colour and technical changes to improve the product.