








JAKA-BKL GmbH  
Jaka Straße 3  
D-32351 Stemwede-Wehdem



ISK51-8E









ISK61-8E



**Service-Hotline**  
**01805-678101**  
0,14€ pro Min.  
**++49 für Österreich**  
Auslandstarif pro Min.  
**service@jaka-bkl.de**  
voor Nederland en België  
**00800-40119350**  
**benelux@jaka-bkl.de**

# Montageanleitung



Ersatzteile/Spare parts/pièces de rechange/Reserveonderdelen/Piezas de recambio/Ricambi/Запасные части/Części zamienne/pótkatárszek/Náhradní části/Nadomestni deli/varaosat/reservdelar/náhradné diely/Utilizaj piese de schimb/Yedek parçalar

ISK51-8E | (J) E941934 (Q) (Q1) E946007 (R) E941932 (S) (S1) E946007 (T) E941937 (W) E946008 (W1) E946009

ISK61-8E | (J) E941935 (Q) (Q1) E946007 (R) E941933 (S) (S1) E946007 (T) E941938 (W) E946008 (W1) E946009

500861.1A 01/19 sl