


SOJAG


produits saisonniers • seasonal products




Sojag code: 999-7161359
CUP/UPC code: 772830161359

Assembly Manual / Guide d'assemblage / Manual de ensamblaje / 조립 설명서 / Montageanleitung






Use the hex keys in the box. / Utilisez les clés hexagonales fournies dans la boîte. / Utilice las llaves hexagonales en la caja. / 상자에 육각 키를 사용 하십시오. / Verwenden Sie die Sechskantschlüssel in der Box.



Please use a Phillips screwdriver. / Utilisez un tournevis de type Phillips / Por favor, use un destornillador Phillips. / 십자 드라이버를 사용 하십시오. / Bitte verwenden Sie einen Kreuzschraubenzieher.



You may need to use a drill for this step. / Vous pouvez avoir besoin d'utiliser une perceuse pour cette étape. / Puede que tenga que utilizar un taladro para este paso. / 이 단계에선 드릴을 사용해야 할 수도 있습니다. / Für diesen Schritt können Sie einen Bohrer verwenden.




Wearing protective gloves is recommended. / Le port de gants de protection est recommandé / El uso de guantes de protección se recomienda. / 보호 장갑을 착용 하는 것이 좋습니다. / Das Tragen von Schutzhandschuhen wird empfohlen.










Two or more people are required at this stage. / Deux personnes ou plus sont nécessaires à cette étape. / Dos o más personas se requieren en esta etapa. / 이 단계에서는 두 명 이상 이 필요합니다. / Für diesen Bauschritt sind 2 oder mehr Personen erforderlich.










Do not tighten screws all the way for now. / Ne pas visser fermement pour l'instant. / No atornille con firmeza por ahora. / 아직 나사를 단단히 조이지 마십시오. / Bitte die Schrauben zum jetzigen Zeitpunkt noch nicht fest anziehen.






Sold separately. / Vendus séparément. / vendido en las opciones. / 옵션 판매 / Optional erhältlich



T1 X 24 (+2) 	V1 X 16 (+2) 
A2 X 209 (+10) 	B2 X 16 (+2) 
C2 X 16 (+2) 	D2 X 25 (+2) 
E2 X 32 (+3) 	F2 X64 (+6) 
H2 X 17 (+2) 	K2 X 4 
K3 X 8 	K4 X 4 
G2 X 1 	Y X 2 



A x4 	B x2 
C x2 	C1 x6 
D x2 	D1 x4 
E x2 	F x4 
G x4 	H x2 
I x2 	J x2 
K x2 	L x2 
A1 x1 	B1 x1 

S X2 	T X2 
U X2 	V X2 
K1 X2 	L1 X4 
M1 X4 	N1 X4 
O1 X4 	P1 X2 
W X1 	X X5 
Y X6 	Z X4 












T1x8



B2x16








R1x4








S1x4






F2x24













































Kx2






Lx2















A2x4








B1x1





A2 x1




Yx2








F1x4











J1x2



E1x4







NOTES

NOTES



Clemens **HobbyTec**

NOCH FRAGEN RUND UM DAS PRODUKT ODER ZUM AUFBAU?

RUFEN SIE UNS AN:
+49 (0) 6571 929 222

SERVICE@CLEMENS-HOBBYTEC.DE

CLEMENS HOBBYTEC GMBH
RUDOLF-DIESEL-STRASSE 8
D-54516 WITTLICH

WWW.CLEMENS-HOBBYTEC.DE