

ASSEMBLY INSTRUCTION

Ax1	Bx1	Cx4	Dx1	Ex2	Fx1	Gx1
Hx1	Jx1	Lx4	Nx10	Px1	Rx1	Sx2
Ix1	Kx1	Mx2	Ox10	Qx1		

①

②

③

④

⑤

⑥