


96796-96797-96798-96799-98386 ADJUSTABLE LED CIRCULAR LUMINAIRES REMOTE CONTROL INSTRUCTIONS

CE 🛣

- 1. Install 2 x AAA batteries (Not supplied) into the remote control.
- 2. On & Off buttons turn the fitting on and Off.
- 3. K-& K+ buttons allow you to adjust the colour temperature to your liking.
- The ★ & ★ buttons adjust the level of brightness (dimming function).
- 5. The () button changes the colour temperature from warm to cool to a mix of both.
- 6. The button puts the light fitting into "Nightlight" mode.
 7. Channel "B" & "C" buttons can be used for controlling additional LED circular light fittings and each channel and light fitting would have to be "paired" as below.



Note: The Light Fitting & the Remote Control have been paired "A channel" at the factory. If the remote control is not working you may need to action the following pairing process.

1. With the light fitting switched Off, long press Channel "A" on the remote control and wait for the LED on the remote control

- to remain a constant RED.
- 2. With the Channel "A" button still pressed down switch on the light fitting. It should initially blink which indicates that the light fitting has been successfully paired.

Specification

Mode	CS-RG12KW1
Color	White
Wireless Technology	5.8G wireless communication
Control distance	30m
Moonlight Mode	Yes
Group Control Yes	Yes
Rotating Mode Yes	Yes
Power	A pair of AAA batteries
Size	150*38.5*12mm
Weight	35g



WWW.QAZQA.COM

