


INSTRUCTION MANUAL



Jochem CL 48 White Smart 103957


Overall size



3600	LM
48	W
2000- 4000K+RGB	K
>80	CRI
30000	H
25000	ON/OFF

Jochie CL 48 Black Smart 103959


Overall size



3600	LM
48	W
2000- 4000K+RGB	K
>80	CRI
30000	H
25000	ON/OFF

Emma CL 51 White Smart 103952


Overall size



3600	LM
48	W
2000- 4000K+RGB	K
>80	CRI
30000	H
25000	ON/OFF

Jochie CL 38 Black Smart 103958


Overall size



1800	LM
24	W
2000- 4000K+RGB	K
>80	CRI
30000	H
25000	ON/OFF

Iene CL 38 White Smart 103955

Overall size



1800	LM
24	W
2000- 4000K+RGB	K
>80	CRI
30000	H
25000	ON/OFF

INSTRUCTION MANUAL


Jochem CL 48 White Smart
103957

Jochie CL 48 Black Smart
103959

Emma CL 51 White Smart
103952

Jochie CL 38 Black Smart
103958

Iene CL 38 White Smart
103955



REMOTE CONTROL MANUAL


Jochem CL 48 White Smart
103957

Jochie CL 48 Black Smart
103959

Emma CL 51 White Smart
103952


Jochie CL 38 Black Smart
103958

Iene CL 38 White Smart
103955



Free APP!

tuya[®]



Tuya APP MANUAL

Jochem CL 48 White Smart
103957

Jochie CL 48 Black Smart
103959

Emma CL 51 White Smart
103952

Jochie CL 38 Black Smart
103958


Iene CL 38 White Smart
103955




ON/OFF, Brightness, CCT changeable, RGB, scene mode can be controlled by mobile-phone !

Mobile APP

Smart Home!!



You can remotely control your LED ceiling lamp at home by mobile-phone as long as the net is in the normal situation!



What is scene mode? Below choices for you:

1. Reading mode
2. Sleeping mode
3. Lighting mode
4. Viewing mode
5. Colorful mode

Mobile APP operation is set up in 4 easy steps

Before you start write down your network name & password.


Note: this item only works on a 2,4GHz Wifi network, not on a 5GHz WiFi network.

Please consult the manual of your router for settings.


1. Download "Tuya Smart" or "Smart Life" from the Apple store, the Andriod or scan the QR code.



2. Open the app. First time user follow on-screen instructions to create your account. To add this lamp start by touching "add device" (+) and follow the on-screen instructions.



3. Turn the lamp on. The lamp will start flashing. (If the lamp or device does not start flashing, switch it on and off 3 times. It will reset the lamp or device.)



4. Follow the on screen prompts to finish installation.

If you get the notification the product only works on 2,4GHz networkes you should change the WiFi-frequency of your network to 2,4GHz only in the setting menu of the router.