




BZR116

SoBuy



TOOLS:



UNIT:MM

1

2

3

4

5

6

7

8

9



UNIT:MM

10

11

12

13

14


15

16

17

18

19



UNIT:MM

A
X
14

B
X
14

CL

CR

DL

DR

E
X
14

F
X
8

G
X
8

H
X
6

J
X
2



M6×35

φ 15×10

350

350

350

350

φ 6×30

M4×30

M6×12

M4×25



Pour en savoir plus:
www.quefairedemesdechets.fr

Stand:02.2023

UNIT:MM

K

L

M

N

O

P

Q

R

S

T

U

V

W

X

14

2

16

2

2

2

M2.5×12

M3.5×12

M4×16

M3×14

M3×10

M4×40

φ 6×30

M4×12

M4

BOLT INSTALLATION AS BELOW:

BOLT

Connecting piece

Adjust connecting piece direction if condition as illustrated

Insert bolt when Connecting piece under Such condition

A1.

A2.

A3.

A4.


1.

2.


3.

4.


5.




6.




7.




8.




9.




10.



11.




12.




13.



14.




15.




16.




17.




18.




19.




20.




21.




22.




23.




24.




25.



26.



27.



28.

