

Meaningful Innovation.

WEEE Number: 80133970

INSTRUCTION MANUAL

FABRIC BELT SERIES LIGHTS



LED DOWN LIGHT VT-41120



LED GLOBE LIGHT VT-41010



LED DOWN LIGHT VT-41020



LED SPOT LIGHT VT-41012



LED DOWN LIGHT VT-41112



TECHNICAL DATA

WARRANT									
MODEL	VT-41012		VT-41112		VT-41010	VT-41020		VT-41120	
SKU	23104	23105	23106	23107	23108	23109	23110	23111	23112
UNIT COLOR	Black	White	Black	White	Black	Black	White	Black	White
WATTS	12W				10W	20W			
LUMENS	800 Lm	900 Lm	800 Lm		900 Lm	1400 Lm	1700 Lm	1200Lm	1100Lm
COLOR TEMPERATURE	3000K								
INPUT VOLTAGE	DC: 48V								
BEAM ANGLE	38°			120°					
LIFE SPAN	25,000 Hours								
ON/OFF CYCLE	>15,000 Times								
PROTECTION RATING	IP20								
CRI	90								
MATERIAL	Aluminium								
DIMENSION	Ø100x	107 mm	Ø100x1	07 mm	Ø150x147 mm	Ø200x	113 mm	Ø300×	(71 mm

INTRODUCTION & WARRANTY

Thank you for selecting and buying V-TAC product. V-TAC will serve you the best. Please read these instructions carefully before starting the installation and keep this manual handy for future reference. If you have any another query, please contact our dealer or local vendor from whom you have purchased the product. They are trained and ready to serve you at the best. The warranty is valid for 3 years from the date of purchase. The warranty does not apply to damage caused by incorrect installation or abnormal wear and tear. The company gives no warranty against damage to any surface due to incorrect removal and installation of the product. The products are suitable for 10-12 Hours Daily operation. Usage of product for 24 Hours a day would void the warranty. This product is warranted for manufacturing defects only.

WARNING

- 1. Please make sure to turn off the power before starting the installation.
- 2. Installation must be performed by a qualified electrician.
- 3. The light source of this luminaire is not replaceable, when the light source reaches its end of life the whole luminaire should be replaced.
- 4. Proper grounding should be ensured throughout the installation.
- The lights works on DC 48V, please connect correctly with the driver before connecting the driver to the power supply main. DO NOT CONNECT DIRECTLY TO THE MAIN SUPPLY.
- 6. For Indoor use only



This marking indicates that this product should not be disposed of with other household wastes.



Caution, risk of electric shock.





COMPLETE INSTALLATION MANUAL QR CODE


Points de collecte sur www.quefairec Privilégiez la réparation ou le don de

Cet appareil, ses accessoires et cordons se recyclent

Please scan the QR code to access the manual in multiple languages.

A. MANDATORY ACCESSORIES (NOT INCLUDED - SOLD SEPARATELY)




















Different ways of installation




B. OPTIONAL ACCESSORIES (NOT INCLUDED - SOLD SEPARATELY)















C. BASIC INSTALLATION





INSTALLATION INSTRUCTIONS

- 1. Switch off the power before installation.
- 2. Connect Luminaire to the belt.
- 3. Make sure to do the mechanical tension adjustment before and after attaching the luminaire.
- 4. Belt end to be connected to either Recessed/ Surface Canopy.
- 5. Connect the wires as per the diagram.
- 6. Switch on the power to test the light.

COMPLETE INSTALLATION INSTRUCTIONS CAN BE FOUND ON THE V-TAC WEBSITE & ARE ALSO ACCESSIBLE VIA THE PROVIDED QR CODE