

Einstellen einer neuen Zahlenkombination und Öffnen/Schließen des VHS 623(H)

- 1) Zum ersten Öffnen des Schlosses die Zahlenkombination 0-0-0-0 einstellen. Den Bügel nach unten drücken, dann das Schloss aufmachen.
- 2) Stellen Sie nun eine eigene Zahlenkombination ein (Achtung: Das Einstellen ist nur möglich, wenn das Schloss geöffnet ist): a. Den mitgelieferten Reset-Schlüssel in das seitliche Loch stecken und um 90 Grad drehen. b. Stellen Sie nun eine eigene 4-stellige-Zahlenkombination ein (vergessen Sie bitte nicht, sich ihre neue Zahlenkombination zu notieren). c. Entfernen Sie den Reset-Schlüssel.
- 3) Durch Eingabe Ihrer 4-stelligen Zahlenkombination und Herunterdrücken des Bügels öffnen Sie das VHS 623(H).



facebook.com/BASIGmbH




@basi_gmbh



www.basi.eu





Setting a new number combination and opening/closing the VHS 623(H)

- 1) To open the lock for the first time, set the number combination 0-0-0-0-0. Press the shackle down, then open the lock.
- 2) Now set your own number combination (note: setting is only possible when the lock is open):
 - a. Insert the supplied reset key into the hole on the side and turn it 90 degrees.
 - b. Now set your own 4-digit number combination (please do not forget to make a note of your new number combination).
 - c. Remove the reset key.
- 3) Open the VHS 623(H) by entering your 4-digit number combination and pressing down on the handle.



facebook.com/BASIGmbH



@basi_gmbh



www.basi.eu

